









Videos and Photos on Your Computer You can connect the F170HD with the included USB cord to your computer to view, transfer, or delete videos and photos stored on the device memory card. Deleting Videos or Pictures 1. Press the MENU button when viewing a video or picture 2. Three options will appear: Delete, Protect, and Slide Show •

22





